

Palintest

Water Analysis Technologies

Bromine, Total LR

Photometric test for Total Bromine (low range) in Pools, Spas and treated waters

COLOUR CHANGE

Colourless to Pink

RANGE:

0 - 10 mg/L Br₂

TECHNICAL RESOURCE:

[Bromine Test Method, Technical Information](#)

01



Fill to the 10 mL line with sample.

02



Use this to "blank" the instrument. Place in cell holder and press Blank.

03



Pour out sample leaving a few drops.

04



Add a DPD 1 tablet to those drops. Then, crush to form a paste.

05



Fill to the 10 mL line with further sample and stir.

06



Place the tube in the cell holder and press Measure to obtain the concentration of Total Bromine.