

Palintest

Water Analysis Technologies

Turbidity

Photometric test for Turbidity in natural and treated water

COLOUR CHANGE

Clear to Cloudy

RANGE:

0 - 1000 FTU

TECHNICAL RESOURCE:

Turbidity Test Method, Technical Information

NOTES:

For lower level turbidity and nephelometric measurement in accordance with ISO 7027, use a Palintest Turbimeter Plus instrument

01



Filter 10 mL of sample through a GF/B filter .

02



Use this to "blank" the instrument. Place in cell holder and press Blank.

03



Fill a second tube to the 10mL line with unfiltered sample.

04



Place in cell holder and press Measure to obtain value for Turbidity. Please note: This not a nephelometric measurement.