



Palintest Ltd

Palintest House
Kingsway
Team Valley
Gateshead
Tyne & Wear
NE11 0NS
England
Tel: +44 (0) 191 491 0808
sales@palintest.com

Palintest Australia Pacific

1/53 Lorraine Street
Peakhurst Business Centre
Peakhurst
NSW 2210
Australia
Tel: +61 1300 131516
palintest@palintest.com.au

Palintest USA

400 Corporate Circle
Suite J
Golden CO
80401
USA
+1 720 221 6878
info@palintestusa.com

Palintest China

Room 1711
Fanli Mansion
22 Chaowai Street
Chaoyang District
Beijing
100020
People's Republic of China
Tel: +86 10 6588 6200
china@palintest.com



www.palintest.com



© Palintest Limited. All rights reserved. Registered office: Palintest House, Kingsway, Team Valley, Tyne & Wear, England NE11 0NS. Registered in England, Number 1204118.

BR-LPTX-04/22-EN

www.palintest.com

Pool & Spa
Water Analysis Technologies



Our Purpose

We exist to safeguard water for everyone, every day.

Palintest
Water Analysis Technologies




Palintest products help to deliver:



Swimmer safety

Safeguard pool users through effective disinfection and water balance control



Pool integrity

Regular pool testing helps maintain your pool and protects the pool infrastructure



Water balance

Maintain optimum water balance to avoid corrosion or scaling



Cost efficiency

Optimise your pool treatment plan

Backed by over 100 years of research, our equipment has been optimised to make testing simple and easy.

Our technology delivers reliable results, to drive confidence in water quality management, so we can all enjoy swimming pools and spas safely.

Lumiso Photometers

The Lumiso Pooltest family of photometers set a new standard for photometry in water testing. Covering a single parameter through to multi parameter testing, Lumiso Pooltest photometers are a robust all-round solution for pool and spa testing needs, allowing users to perform reliable accurate testing anywhere, with little to no prior knowledge or training.

Features of the Lumiso family:

-  The Lumiso Optical Engine uses innovative photometric technology and is utilised across the full Lumiso Pooltest family, giving consistently accurate and reliable results across all models
-  Simple user interface requires little prior knowledge or training
-  Logs test results with date and time for compliance and auditing
-  Interchangeable accessories and reagents across the full Lumiso Pooltest family range simplifies inventory
-  USB connectivity enables data management with the Palintest Connect platform
-  Designed and manufactured in the UK



The Lumiso Pooltest family also benefits from a new kit design which includes a waterproof reagent box. The waterproof design protects from any water damage and minimises the overall amount of packaging used in the kits.



Which Lumiso instrument is right for me?

The Lumiso pooltest range includes four instruments, each designed to meet the needs of different testing environments and users.

Lumiso Pooltest 3



Lumiso Pooltest 3 is ideal for monitoring of outdoor pools, covering the three main tests chlorine, pH and cyanuric acid.

Lumiso Pooltest 4



Lumiso Pooltest 4 is ideal for testing spas and indoor pools, inclusive of tests for alkalinity, bromine, chlorine and pH.

Lumiso Pooltest 6



The Lumiso Pooltest 6 provides simple and effective pool testing for Service Engineers and Pool Managers. Inclusive of all the tests required for a water balance calculation: alkalinity, bromine, calcium hardness, chlorine, cyanuric acid and pH.

Lumiso Pooltest Expert



The Lumiso Pooltest Expert has been designed for a range of Pool and Spa customers from Pool Managers through to professional Engineers who need to test pool and spa water multiple times daily, quickly, and accurately across key and troubleshooting parameters.

Pool Photometer Comparison Table

| Photometer | Lumiso Pooltest 3 | Lumiso Pooltest 4 | Lumiso Pooltest 6 | Lumiso Pooltest Expert |
|---|-------------------|-------------------|-------------------|------------------------|
| PARAMETER | | | | |
| Absorbance | | | | • |
| Acid Demand | | | | • |
| Alkalinity, Total | | • | • | • |
| Aluminium | | | | • |
| Ammonia (Tablet Indophenol) | | | | • |
| Bromine, Free, Combined & Total | | • | • | • |
| Bromine, Total | | • | • | • |
| Bromine, Total (+ Cl ₂ , F, C & T) | | • | • | • |
| Bromine, Total (Cl ₂ present) | | • | • | • |
| Calcium Hardness | | | | • |
| Calcium Hardness (Salt Pools) | | | | • |
| Chlorine Dioxide | | | | • |
| Chlorine HR | | | | • |
| Chlorine, F, C & T (Liquid) | • | • | • | • |
| Chlorine, F, C & T (Tablet) | • | • | • | • |
| Chlorine, Free | • | • | • | • |
| Chlorine, Free & Total (XF, XT) | • | • | • | • |
| Chlorine, Free (XF) | • | • | • | • |
| Chlorine, Total | • | • | • | • |
| Copper, Free | | | | • |
| Copper, Free and Total | | | | • |
| Cyanuric Acid | • | | • | • |

| Photometer | Lumiso Pooltest 3 | Lumiso Pooltest 4 | Lumiso Pooltest 6 | Lumiso Pooltest Expert |
|-------------------------------|-------------------|-------------------|-------------------|------------------------|
| PARAMETER | | | | |
| Hardness, Total | | | | • |
| Hydrogen Peroxide HR | | | | • |
| Iron MR | | | | • |
| Langelier Water Balance Index | | | | • |
| Nitrate | | | | • |
| Ozone | | | | • |
| pH-Phenol Red | • | • | • | • |
| Salt | | | | • |
| Sulfate | | | | • |
| Transmittance | | | | • |
| Zinc | | | | • |
| Zinc (copper present) | | | | • |





Lumiso Pooltest 3

Tests for:

Chlorine (Free, Combined & Total)

Cyanuric Acid

pH Phenol Red



FEATURES INCLUDE:

Ideal for monitoring of outdoor pools

Logs test results with date and time

USB connectivity enables further data management

On-board memory for up to 50 data sets

Lightweight kit design

Easy to operate

Quick to deliver results

Tag records with labels

IP67 Certified Waterproofing

Technical Specification

| | |
|------------------------------------|---|
| Instrument Type | Dual light source colorimeter offering direct-reading of pre-programmed test calibrations |
| Peak Wavelengths | 530 nm, 575 nm |
| Accuracy | ± 1.0% T |
| Display | 226 x 138 pixel LCD with backlight |
| User Interface | Language-free interface, on screen visual icons |
| Size (W x L x H) and Weight | 163 mm x 70 mm x 45 mm, 275 g |
| IP Rating | IP67 |
| Power Supply | 3 x AA 1.5V Batteries |
| Connectivity | USB for data download and software updates |
| Memory Capacity | Last 10 results. Blank value held in memory until power off or new blank recorded |

Kit Contents

| Item | Lumiso Pooltest 3 LMP003 |
|------------------------------|--------------------------|
| Lumiso Pooltest 4 instrument | 1 |
| Instructions | 1 |
| Test tubes | 5 |
| Test tube brush | 1 |
| Lint free cloth | 1 |
| 10 mL syringe | 1 |
| Dilution tube | 1 |
| Crush/stir rods | 4 |
| USB lead | 1 |
| Initial reagent pack | 1 |
| Hard carry case | 1 |

Reagents included in kit

| Type of reagent | Tests |
|----------------------|-------|
| Free Chlorine DPD 1 | 50 |
| Total Chlorine DPD 3 | 50 |
| DPD XF Chlorine | 30 |
| DPD XT Chlorine | 30 |
| Phenol Red | 50 |
| Alkalinity | 10 |

For the full list of reagents see page 18

Lumiso Pooltest 4

Tests for:

- Bromine
- Chlorine (Free, Combined & Total)
- pH Phenol Red
- Total Alkalinity



FEATURES INCLUDE:

- Ideal for testing spas and indoor pools
- Logs test results with date and time
- USB connectivity enables data management
- On-board memory for up to 50 data sets
- Lightweight kit design
- Easy to operate
- Quick to deliver results
- Tag records with labels
- IP67 Waterproofing

Technical Specification

| | |
|-----------------------------|---|
| Instrument Type | Dual light source colorimeter offering direct-reading of pre-programmed test calibrations |
| Peak Wavelengths | 530 nm, 575 nm |
| Accuracy | ± 1.0% T |
| Display | 226 x 138 pixel LCD with backlight |
| User Interface | Language-free, on-screen visual icons |
| Size (W x L x H) and Weight | 163 mm x 70 mm x 45 mm, 275 g |
| IP Rating | IP67 |
| Power Supply | 3 x AA 1.5V Batteries |
| Connectivity | USB for data download and software updates |
| Memory Capacity | Up to 50 data sets |

Kit Contents

| Item | Lumiso Pooltest 4 LMP004 |
|------------------------------|--------------------------|
| Lumiso Pooltest 4 instrument | 1 |
| Instructions | 1 |
| Test tubes | 5 |
| Test tube brush | 1 |
| Lint free cloth | 1 |
| 10 mL syringe | 1 |
| Dilution tube | 1 |
| Crush/stir rods | 4 |
| USB lead | 1 |
| Initial reagent pack | 1 |
| Hard carry case | 1 |

Combine with a TDS meter for complete compliance to HGS:282 UK Spa Regulations

Reagents included in kit

| Type of reagent | Tests |
|----------------------|-------|
| Free Chlorine DPD 1 | 50 |
| Total Chlorine DPD 3 | 50 |
| DPD XF Chlorine | 30 |
| DPD XT Chlorine | 30 |
| Phenol Red | 50 |
| Alkalinity | 10 |

For the full list of reagents see page 18



Lumiso Pooltest 6

Tests for:

- Bromine
- Calcium Hardness
- Chlorine (Free, Combined & Total)
- Cyanuric Acid
- pH Phenol Red
- Total Alkalinity



FEATURES INCLUDE:

- Ideal for Service Engineers and Pool Managers
- Enables a complete water balance calculation
- Expert colorimetric analysis
- Logs test results with date and time
- USB connectivity enables data management
- On-board memory for up to 50 data sets
- Lightweight kit design
- Tag records with labels
- IP67 Waterproofing

Technical Specification

| | |
|------------------------------------|---|
| Instrument Type | Dual light source colorimeter offering direct-reading of pre-programmed test calibrations |
| Peak Wavelengths | 530 nm, 575 nm |
| Accuracy | ± 1.0% T |
| Display | 226 x 138 pixel LCD with backlight |
| User Interface | Language-free, on screen visual icons |
| Size (W x L x H) and Weight | 163 mm x 70 mm x 45 mm, 275 g |
| IP Rating | IP67 |
| Power Supply | 3 x AA 1.5V Batteries |
| Connectivity | USB for data download and software updates |
| Memory Capacity | Up to 50 data sets |

Kit Contents

| Item | Lumiso Pooltest 6 LMP006 |
|------------------------------|--------------------------|
| Lumiso Pooltest 6 instrument | 1 |
| Instructions | 1 |
| Test tubes | 5 |
| Test tube brush | 1 |
| Lint free cloth | 1 |
| 10 mL syringe | 1 |
| Dilution tube | 1 |
| Crush/stir rods | 4 |
| USB lead | 1 |
| Initial reagent pack | 1 |
| Hard carry case | 1 |

For the full list of reagents see page 18

Reagents included in kit

| Type of reagent | Tests |
|----------------------|-------|
| Free Chlorine DPD 1 | 50 |
| Total Chlorine DPD 3 | 50 |
| DPD XF Chlorine | 30 |
| DPD XT Chlorine | 30 |
| pH Phenol Red | 50 |
| Cyanuric Acid | 10 |
| Alkalinity | 10 |
| Calcium Hardness | 10 |



Lumiso Pooltest Expert

Tests for:

Absorbance
Acid Demand
Alkalinity, Total
Aluminium
Ammonia (Tablet Indophenol)
Bromine, Total
Bromine, Total (Cl₂ present)
Calcium Hardness
Calcium Hardness (Salt Pools)
Chlorine and Chloramines
Chlorine Dioxide
Chlorine HR
Chlorine, Free
Chlorine, Free & Total (XF, XT)
Chlorine, Free (XF)
Chlorine, Total
Copper, Free
Copper, Free and Total
Cyanuric Acid
Hardness, Total
Hydrogen Peroxide HR
Iron MR
Langelier Water Balance Index
Nitrate
Ozone
Ozone (Cl₂ or Br₂ present)
Persulfate
Phosphate LR
pH-Phenol Red
Salt
Sulfate
Transmittance



Technical Specification

| | |
|----------------------------------|--|
| Instrument Type | Multiparameter Photometer |
| Wavelengths | 530 nm, 575 nm, 620 nm |
| Peak Wavelengths | ±2 nm |
| Accuracy | +/-1%T |
| Display | Full Colour TFT - 16:9 ratio screen, resolution 800 x 480 px |
| User Interface | PCAP touch panel |
| Size W x L x H (mm) | 211 x 195 x 52 |
| Weight (kg) | 0.85 |
| IP Rating & Standards | IP67 |
| Power Supply | 6 x AA 1.5V Batteries or Standalone USB |
| Connectivity | Via Windows App (USB) or Mobile App (QR Code) |
| Memory Capacity | Access to 1,000 results via device's screen |
| Battery Life | 5,000 tests on one charge |
| Certifications | EN61326, EN61010, IP67 and EN60068-2-78 |

FEATURES INCLUDE:

Designed and manufactured in the UK

Recycled material case

IP67 Waterproofing

Multi parameter for troubleshooting

Quick and accurate testing

Large touch screen interface

Simple to follow on screen instructions

Data traceability for audit compliance

Easy results retrieval with Palintest Connect

Professional level results in-situ

Kit Contents

| Item | All kits |
|-----------------------------------|----------|
| Lumiso Pooltest Expert Instrument | 1 |
| Dilution Tube | 1 |
| Syringe, Luer Slip, 10mL | 1 |
| Polishing Cloth | 1 |
| Test Tube Brush, 12cm | 1 |
| USB lead | 1 |
| Quick Start Guide | 1 |
| Absorbent Cloth | 1 |
| Crush/Stir Rod | 10 |
| Cap for 15mL Vial | 10 |
| 15mL Snap Cap Vial | 10 |
| Lumiso Benchtop Case | 1 |
| Reusable Reagent Box | 1 |



Reagents included in kit

| | UK / Rest of World Kit Order code: LMPXUK | USA Kit Order code: LMPXUS | Australia Kit Order code: LMPXAUS |
|--|--|-------------------------------------|--------------------------------------|
| | DPD1 Free Chlorine Tablet 0-5 mg/L | DPD XF Chlorine Tablet 0 - 10 mg/L | DPD1 Free Chlorine Tablet 0-5 mg/L |
| | DPD3 Total Chlorine Tablet 0-5 mg/L | DPD XT Chlorine Tablet 0 - 10 mg/L | DPD3 Total Chlorine Tablet 0-5 mg/L |
| | DPD4 Total Chlorine Tablet 0-5 mg/L | Cyanuric Acid Tablet 0 - 200 mg/L | DPD4 Total Chlorine Tablet 0-5 mg/L |
| | Cyanuric Acid Tablet 0 - 200 mg/L | pH, Phenol Red Tablet 6.8 - 8.4 | DPD XF Chlorine Tablet 0 - 10 mg/L |
| | pH, Phenol Red Tablet 6.8 - 8.4 | Coppercol No 1 Tablet 0 -5 mg/L | DPD XT Chlorine Tablet 0 - 10 mg/L |
| | Coppercol No 1 Tablet 0 -5 mg/L | Coppercol No 2 Tablet 0 -5 mg/L | Cyanuric Acid Tablet 0 - 200 mg/L |
| | Coppercol No 2 Tablet 0 -5 mg/L | Alkalinity Total Tablet 0 - 500mg/L | pH, Phenol Red Tablet 6.8 - 8.4 |
| | Alkalinity Total Tablet 0 - 500mg/L | Calcium Hardness Tablet 0 - 500mg/L | Coppercol No 1 Tablet 0 -5 mg/L |
| | Calcium Hardness Tablet 0 - 500mg/L | Iron MR No1 Tablet 0 -5 mg/L | Coppercol No 2 Tablet 0 -5 mg/L |
| | Iron MR No1 Tablets 0 -5 mg/L | Iron MR No2 Tablet 0 -5 mg/L | Alkalinity Total Tablet 0 - 500mg/L |
| | Iron MR No2 Tablets 0 -5 mg/L | Oxystop Tablet N/A | Calcium Hardness Tablet 0 - 500mg/L |
| | | Phosphate LR, Phot, 0-4mg/L | Iron MR No1 Tablet 0 -5 mg/L |
| | | | Iron MR No2 Tablet 0 -5 mg/L |

Photometer reagents

Photometer reagents

| Name | Part code (AP) 250 Tablets | Part code (PM) 50 Tablets | Part Code AT (Liquid) | Range |
|--|-------------------------------|------------------------------|--------------------------|------------|
| Absorbance | | | | 0-2.3 Abs |
| Acid Demand | AP188 | PM188 | | 0-9 mmol/L |
| Alkalinity, Total | AP188 | PM188 | | 0-500 mg/L |
| Aluminium | AP166 | PM166 | | 0-0.5 mg/L |
| Ammonia (Tablet Indophenol) | AP152 | PM152 | | 0-1 mg/L |
| Bromine, Free, Combined & Total | AP060 | PM060 | | 0-10 mg/L |
| Bromine, Total | AP060 | PM060 | | 0-10 mg/L |
| Bromine, Total (+ Cl ₂ , F,C & T) | AP060 | PM060 | | 0-10 MG/L |
| Bromine, Total (Cl ₂ present) | AP060 | PM060 | | 0-10 mg/L |
| Calcium Hardness | AP252 | PM252 | | 0-500 mg/L |
| Calcium Hardness (Salt Pools) | AP252 | PM252 | | 0-500 mg/L |
| Chlorine Dioxide | AP052 | PM052 | | 0-10 mg/L |
| Chlorine HR | AP162 | PM162 | | 0-250 mg/L |
| Chlorine, F, C & T (Liquid) | | | AT015 / AT035 | 0-5 mg/L |
| Chlorine, F, C & T (Tablet) | AP031 | PM031 | | 0-5 mg/L |
| Chlorine, Free | AP011 | PM011 | | 0-5 mg/L |
| Chlorine, Free & Total (XF, XT) | AP033 | PM033 | | 0-10 mg/L |

| Name | Part code (AP) 50 Tablets | Part code (PM) 250 Tablets | Part Code AT (Liquid) | Range |
|-------------------------------|------------------------------|-------------------------------|--------------------------|--------------|
| Chlorine, Free (XF) | AP013 | PM013 | | 0-10 mg/L |
| Chlorine, Total | AP041 | PM041 | | 0-5 MG/L |
| Copper, Free | AP187 | | | 0-5 mg/L |
| Copper, Free and Total | AP186 | PM186 | | 0-5 mg/L |
| Cyanuric Acid | AP087 | PM087 | | 0-200 mg/L |
| Hardness, Total | AP254 | PM254 | | 0-500 mg/L |
| Hydrogen Peroxide HR | AP105 | PM105 | | 0-100 mg/L |
| Iron MR | AP292 | PM292 | | 0-5 mg/L |
| Langelier Water Balance Index | N/A | N/A | | |
| Nitrate | AP163 | PM163 | | 0-1 mg/L |
| Ozone | AP056 | PM056 | | 0-2 mg/L |
| pH-Phenol Red | AP130 | PM130 | | 6.8 - 8.4 |
| Salt | AP268 | PM268 | | 0-10000 mg/L |
| Sulfate | AP154 | PM154 | | 0-200 mg/L |
| Transmittance | | | | 0-100 %T |

Only Palintest reagents are compatible with Palintest photometers



Photometer Check Standards, accessories and support



LMC001

FEATURES INCLUDE:

Validate the performance of your instrument with Palintest Check Standards

Quick and easy method

Traceable to national standards

Supplied with a certificate

Ordering Information

Pooltest 3, 4 & 6 NDF Check Standards

LMC001

Neutral Density Filter (NDF) check standard set, supplied in a protective case. Includes two standards and a blank.

Lumiso Pooltest Expert NDF Check Standards

LMCPTX

Neutral Density Filter (NDF) check standard set, supplied in a protective case. Includes one standard and a blank.

Accessories

| Description | Code |
|---|-------|
| Pack of 5 glass test tubes | PT555 |
| Rack for 8 x Lumiso test tubes | PT545 |
| Pack of 10 crush / stirring rods | PT502 |
| Syringe 10 mL | PT369 |
| Sample tube brush, length 120 mm | PT663 |
| Sample container 100/50/10 mL plastic tube | PT510 |
| Palintest dilution tube, x2, x3, x4, x5, x10, plastic | PT512 |
| Wash bottle, 250ml | PT516 |
| Wash bottle (for deionised water) | PT518 |
| Sample container, 50/10 ml plastic bottle | PT519 |
| Sample container, 20/10 ml plastic tube | PT526 |
| Polishing Cloth | PT399 |
| Test Tube Brush, 12cm | PT663 |
| USB lead* | PT749 |

*Lumiso Pooltest Expert specific accessory

Technical Support

At Palintest we pride ourselves on the technical support that we provide to our customers.

We have used our expertise built up over 100 years to develop an extensive library of information which helps to support your needs.

For more information visit our website or contact our team on sales@palintest.com

Servicing

Ensure your photometer remains in optimal condition with an instrument service. To get the best out of your photometer, Palintest recommends an annual service.

What is included in a Palintest service?

- Thorough evaluation and inspection of your instrument
- Comprehensive clean of the test chamber and optical bench
- Recalibration of your instrument
- Update of the latest software to optimise the performance of your instrument

Contact sales@palintest.com for further information on servicing.

Product Registration and Warranty

Each of our photometers come with a two year warranty.

To register and receive updates about your instrument, please visit: www.palintest.com/en/product-registration

Contour Comparator Kits

Single and dual parameter kits for cost effective pool, spa and hot tub testing



FEATURES INCLUDE:

- Single and dual parameter test kits
- Unique petal disks for easy colour differentiation
- Tablet methods for visual colour development

Single Parameter Contour Comparator Kits

Kits includes: Contour Comparator, Contour disk with instructions, 3 cuvettes, cuvette brush, crush/ stir rod, reagents for 30 tests, supplied in a hard case

| Product | Code |
|---|------------|
| Comparator Kit, Free and Total Chlorine, 0-5 mg/L | CKH1001 |
| Comparator Kit, Free and Total Chlorine, 0-2 mg/L | CKH1002 |
| Comparator Kit, Free and Total Chlorine, 0-1 mg/L | CKH1003 |
| Comparator Kit, Bromine, 0-8 mg/L | CKH1005 |
| Comparator Kit, Alkalinity, 0-250 mg/L | CKH1192 |
| Comparator Kit, Chlorine HR, 0-250 mg/L | CKH162/250 |
| Comparator Kit, Hydrogen Peroxide, 0-100 mg/L | CKH1105 |
| Comparator Kit, Ozone, 0-1 mg/L | CKH1056 |
| Comparator Kit, Phosphate, 0-4 mg/L | CKH1177 |
| Comparator Kit, pH Phenol Red, pH 6.8-8.4 | CKH1131 |

Dual Parameter Contour Comparator Kits

Kits includes: Contour Comparator, 2 Contour disks with instructions, 3 cuvettes, cuvette brush, crush/stir rod, reagents for 30 tests for each parameter, supplied in a hard case.

| Product | Code |
|--|---------|
| Free + Total Chlorine/ Phenol Red 0-5 mg/l Cl ₂ / pH 6.8-8.4 | CKH2001 |
| Free + Total Chlorine/ Phenol Red 0-2 mg/l Cl ₂ / pH 6.8-8.4 | CKH2002 |
| Free + Total Chlorine/ Phenol Red 0-1 mg/L Cl ₂ / pH 6.8-8.4 | CKH2003 |
| Bromine/ Phenol Red 0-8 mg/L Br ₂ / pH 6.8- 8.4 | CKH2005 |



Balanced Water Kits

Simple visual kits to maintain the water balance of your pool or spa and minimise running costs



FEATURES INCLUDE:

- Portable water balance testing
- Assess likelihood of scaling or corrosion
- Tablet method for visual colour development

Kit Contents

| | SP 129 | SP129C |
|--|--------|--------|
| Standard Comparator | | |
| Contour Comparator | • | • |
| Chlorine 0-5 mg/l disc | • | • |
| Bromine 0-8mg/l disc | | |
| pH Phenol Red disc | • | • |
| 4 Comparator Cuvettes | • | • |
| Cuvette Brush | • | • |
| Crush/Stir Rod | • | • |
| Dilution Tube | • | • |
| Sample Container (100 mL) | | |
| Double Tube Assembly | | • |
| Cyanuric Acid Reagents | | • |
| Reagents Free and Total Chlorine/Bromine | • | • |
| Reagents pH Phenol Red | • | • |
| Tablet count reagents Alkalinity | • | • |
| Tablet count reagents Calcium Hardness | • | • |
| Instructions | • | • |

Comparator Kit Reagents



Only Palintest comparator reagents are compatible with Palintest comparators

Comparator Kit Reagents

| Name | Range | Replacement Pack (250 tests) |
|---------------------------------|-------------------------------|------------------------------|
| Calcium Hardness (Tablet count) | 0-500 mg/L CaCO ₃ | AS077 |
| Total Alkalinity (Tablet Count) | 0-1200 mg/L CaCO ₃ | AS072 |



Pooltester Kits

Ideal for the residential user, the Pooltester range from Palintest provides simple and cost effective pool and hot tub testing



FEATURES INCLUDE:

- Available in a range of key parameters
- Quick colour development
- Cost effective testing solution
- Case made from 100% recycled plastic

Products

| Product | Code |
|--|--------|
| Chlorine/pH Pooltester | SPT610 |
| Chlorine (0-5 mg/L)/pH/Alkalinity Pooltester | SPT612 |
| Chlorine (0-3 mg/L)/pH/Alkalinity Pooltester | SPT614 |
| Bromine/pH/Alk Pooltester | SPT616 |
| Cyanuric Acid Pooltester | SPT620 |

Rapid Reagents for Pooltesters

Palintest Rapid tablets are designed to deliver the active reagent quickly without the need for crushing or handling



Replacement Reagents

| Name | 50 tests | 100 tests | 250 tests |
|----------------------------|----------|------------|-----------|
| Alkalinity (Alkavis) | AL192B | | AK192 |
| Cyanuric Acid | AL087B | | AT087 |
| pH (Phenol Red) | AL131B | AL131/100B | AT130 |
| Chlorine / Bromine (DPD 1) | AL010B | AL010/100B | AT010 |
| DPD 3 | | | AT030 |
| DPD 4 | | | AT040 |

Pooltester Refill Packs

| Name | Range |
|---|--------|
| 30 tests each of Free Chlorine and pH | AL003B |
| 30 tests each of Free Chlorine, pH and Alkalinity | AL004B |
| 20 tests each of Peroxtest and pH | AL623B |

Only Palintest rapid reagents are compatible with Palintest pooltesters

Pool Test Strips

Available in 3-way and 6-way formats to support all residential pool and hot tub users, Palintest test strips are the simplest method for testing your water



FEATURES INCLUDE:

- Available in 3 in 1 and 6 in 1
- No additional reagents required
- No additional equipment required
- Quick and easy method

| Description | Code |
|--|--------|
| Free Chlorine, pH and Alkalinity Pack of 50 | PTJ634 |
| Free Chlorine, Total Chlorine/Bromine, pH, Cyanuric Acid, Hardness and Alkalinity Pack of 50 | PTJ637 |



Connect

Upload, view and manage your data easily with our cloud-based data management software.



Product Registration – register your Lumiso and receive the latest firmware update when you connect your instrument



Data Management – upload and view test results and create reports for monitoring over time



Remote supervision – create a collaboration group to share and monitor test results



Corrective actions – trigger email notifications to advise when test results don't meet target values



Compliance – automatically create an auditable data log when uploading your data



Training – access training materials with step-by-step instructions to help you get the most from your Lumiso